

Important information – read before installing

- Check if materials are as ordered and as specified.
- Check if materials are free from damage.
- Make sure that all rolls have the same batch number.
- If after hanging three widths faults appear, stop immediately and contact the supplier. No claims will be accepted when more widths are hung.
- Ensure site is not too cold and that ventilation is good during hanging and drying.
- Ideal temperature between 15°C and 25°C
- All strips have to be positioned in the same direction on the wall.
- STOP IF YOU THINK THE RESULT MAY NOT BE ACCEPTABLE.
- Keep all labels until after the job has been accepted.

Surface preparation

- Completely remove old wallcovering.
- The surface needs to be sound, dry, free from dust and grease; smooth and slightly absorbing.
- Where mould has occurred, or could occur, treat walls with anti-mould.
- Lighter colour wallcoverings require a surface of a uniform colour.
- New walls should be primed first with wallcovering primer to seal the dry wall.

Pick a starting point

- The best place to start and finish wallcovering is in a corner.
- Mark a plumb line minus 2 cm of the width of the wallcovering away from the corner.

Cutting your wallcovering

- Carefully measure the length required (normally the height of the wall) and cut from the roll, allowing an extra 5 cm at top and an extra 5 cm at the bottom.
- Fold the wallcovering and cut with a sharp utility knife.
- Ensure the pattern is the right way up.
- Before cutting the next lengths ensure that the pattern matches up with previous ones.

Apply wallcovering paste

- Use a liquid glue for heavy wallcovering.
- Apply the glue equally on the wall with brush or applicator.
- Do not glue the complete width, leave approximately 10 cm without glue on the side where the next lane will be positioned.

Hang the first lane of wallcovering

- Gently roll the lanes with the back on the outside ensuring the pattern is the right way up.
- Hang the first strip along the pre-marked plumb line.
- Holding the top of the length, carefully open the fold and lightly stick the top half of the length to the wall.
- When the lane is in the right position smooth the paper against the wall with your hands, beginning in

the middle of the width and working your way across. Continue with the lower part of the lane.

- Position this part against the wall with your hands and a spatula.
- Use a spatula to smooth out any air bubbles.
- Work in a downward motion.
- Trim the excess wallcovering.
- Use a wide-blade putty knife to hold down the top of the wallcovering strip at the ceiling and use a utility knife to trim the excess wallcovering.
- Make sure the utility knife is sharp. Replace the blade after each lane.
- Repeat at the bottom of the lane. Carefully clean any paste from the ceiling and baseboard.

Hang the second lane of wallcovering

- Gently remove a full height 10 cm of the first lane next to the plumb line.
- Paste half width of the wallcovering on the left of the plumb line for the second lane.
- Gently press down the first lane.
- Paste the remaining half width into the corner.
- Position the second lane 1mm next to the first one and position the second lane in place.
- Butt the joints together and never rub the joints.
- Press the lane and evacuate bubbles with a spatula – work in a vertical direction.
- Press the lane into the corner and trim the excess wallcovering.
- Repeat this for the top and bottom of the lane.
- Press the joints extra with a hard roller.
- Be careful with glue marks on the textile surface.
- Those have to be removed immediately with absorbing paper, do not ever rub the glue into the textile and do not use water.

Hang the third lane of wallcovering

- Continue on the right of the first lane.
- Gently remove a full height 10 cm of the first lane.
- Paste half width of the wallcovering.
- Gently press down the first lane.
- Paste the remaining half width of the third lane and position the third lane.
- Proceed as you did for the previous lanes.
- Repeat this procedure for all next lanes.

Cleaning and maintenance

- Textile wall coverings can be brushed and vacuumed.
- More resistant stains can be removed by rubbing carefully with a dry cloth.
- Never use water as this may cause shrinkage and marks.

Tolerances

- Slanted weave construction : 1%
- Width : +/- 2 cm
- Up to maximum 3 pieces per roll

**To see the hanging instructions,
click on the link below:**
vimeo.com/45450272



ASANDERUS®

BY CALCUTTA INTERIORS